

The Difference Between a Transparent Filler and Clear Coat on Visible Carbon Fiber

Beitrag von „Albert Motorsport“ vom 16. Oktober 2026, 19:30

The Difference Between a Transparent Filler and Clear Coat on Visible Carbon Fiber



The key difference is simple: **the transparent filler prepares and levels the surface, while the clear coat provides the final protective layer and desired finish.** Both products serve different purposes when creating a high-quality visible carbon fiber finish.

1. Transparent Filler vs. Clear Coat

Transparent Filler

Purpose: Fill pores and level the surface

- Fills small pinholes, pores, and surface imperfections.
- Builds up material so the surface can be sanded flat.
- Preserves the visible carbon fiber weave.
- Is generally sanded after curing to achieve a smooth, even surface.

Goal: To create a smooth, uniform, and virtually pore-free foundation for the subsequent coating process.

Clear Coat

Purpose: Protect the surface and create the final finish

- Produces the desired glossy or matte appearance.
- Protects against environmental exposure, abrasion, and, depending on the product, UV radiation.
- Enhances the visual depth and appearance of the carbon fiber weave.
- Serves as the final coating layer.

Goal: To achieve a high-quality appearance and a durable, protective surface.

2. Why Isn't Clear Coat Alone Enough?

Clear coat is not a reliable substitute for filling open pores in carbon fiber. If it is applied directly to a porous surface, small holes may remain visible or become more noticeable during the coating process.

A transparent filler, on the other hand, is specifically designed to close these imperfections. After curing, the filler is sanded flat before the clear coat is applied.

3. The Correct Coating Process for Visible Carbon Fiber

The typical coating sequence is:

1. **Carbon fiber laminate:** Inspect and prepare the surface, ensuring it is clean and free from contaminants.
2. **Transparent filler:** Apply a suitable transparent filler to close pores and fill minor surface imperfections.
3. **Curing and sanding:** Allow the filler to cure according to the manufacturer's instructions, then sand it carefully until the surface is smooth and level.
4. **Clear coat:** Apply a compatible clear coat to provide protection, gloss, and visual depth.
5. **Final finishing:** If necessary, sand and polish the cured clear coat according to the coating manufacturer's recommendations.

Depending on the resin system, surface condition, and coating products used, additional coats or intermediate steps may be required.

A professional visible carbon fiber finish requires more than simply applying clear coat. The transparent filler plays a crucial role in closing pores and leveling the surface without obscuring the characteristic carbon fiber weave.

Only after the surface has been properly filled, cured, and sanded should the final clear coat be applied.

The golden rule: First, fill and level the carbon fiber surface with a suitable transparent filler. Then apply the clear coat to achieve the final protective and aesthetic finish.

Important: Not every transparent filler is suitable for visible carbon fiber. The product must remain transparent after curing, be suitable for sanding, and be compatible with both the underlying resin and the subsequent clear coat system.