Questions abeout the factory engine oil level sensor 997.1

Beitrag von "Albert Motorsport" vom 11. April 2023, 14:08

Hello Rafael,

The display only works with the sensor 99660614000 which is installed as standard in the 996/997/991gen1 Cup.

With this you can not measure resistance values at min and max. The sensor requires active electronics to measure the level. The sensor has a resistance of 22 ohms at rest.

If the sensor is now immersed in oil, it still shows 22 ohms.

If they can measure different values with their sensor, it is a different sensor and must then be exchanged for the 99660614000.

Best regards

Jürgen Albert